

How to install GRV-ATEX-PRO **GROOVE-TEX** Reinforcing Paper

- Make sure the drywall surface is free of dust and debris; to accomplish this, you can use a moist towel and remove all drywall dust left behind from the milling process.
- Apply GRV-ATEX-PRO to the milled side of the drywall (the back); this side can be brown or light gray in color. **Do Not Use this material on the opposite side of the drywall.**
- GRV-ATEX-PRO has one side with adhesive; the other one does not. To determine which side has the adhesive, You can wet your thumb and index finger, then touch both sides of the paper to determine which side has the adhesive.
- We strongly recommend that you create a jig or template that matches the exact profile you need to achieve with the drywall. Then place your radius drywall profile securely on the template.
- Using the TapeTech VSPRAY2L Sprayer, or other suitable application method, wet the GRV-ATEX-PRO, making sure you have applied water evenly on the entire surface.
- Apply the paper to the milled side of the drywall. Apply pressure with a roller, hands, or other suitable tools. **NOTE:** It is highly recommended to use 2 people to apply the GRV-ATEX-PRO onto the drywall profile to make sure it has enough pressure to eliminate any air bubbles.
- Is very important to allow the GRV-ATEX-PRO to set at least 20 minutes before moving the profile.

Recommended Items:

AMES ASPIDERX15 Heavy Duty Expandable Work Support



TapeTech VSPRAY2L 2-liter Pressure Sprayer

