

ETURNTABLE Material Support Turntable User Manual




TapeTech Tools

1327 Northbrook Parkway, Suite 400 Suwanee, GA 30024

1-844-TT-TOOLS www.tapetech.com

ETURNTABLE Material Support Turntable Key Components



ETURNTABLE Material Support Turntable User Manual

The **TapeTech ETURNTABLE Material Support Turntable** is a professionalgrade accessory designed to securely hold EPS/XPS foam panels while cutting, grooving or spreading adhesive when working on a scaffold or swing stage.

Installation of the Turntable to the Scaffold or Swing Stage

A. Attach the Bracket Assembly

- 1. Slide the Upper Rail Attachment Bracket over the top of the upper rail of the scaffold or stage.
- 2. Slide the lower end of the Adjustable Post up until the Lower Rail Attachment Bracket hooks the center rail of the scaffold or stage.
- 3. Tighten the Rail Attachment Adjustment Knob.
- 4. Tighten the Bracket Attachment Knob to secure the bracket assembly to the upper rail of the scaffold or stage.
- B. Attach the Turntable to the Bracket Assembly
- 1. Slide the Mounting Post of the turntable into the Receiver on the Mounting Plate.
- 2. Secure the turntable to the Mounting Plate using the Cotter Pin.
- 3. Slide the slots of the Mounting Plate onto the bolts on the top of the bracket assembly.
- 4. Tighten the Mounting Plate Adjustment Knobs.


Using the Turntable

- 1. Position a foam panel on top of the four Positioning Pins
- 2. Press down to secure the foam panel in place
- 3. Rotate the turntable to the desired position
- 4. Complete the cut, groove or material application
- 5. Remove EPS/XPS foam by lifting the panel off the positioning pins

Specifications

Turntable Width: 12.2" (310mm) Turntable Length: 21.2" (540mm) Maximum Allowable Diameter of Rail: 2.125" (54mm) Minimum Distance Between Rail Centers: 14.2" (360mm) Maximum Distance Between Rail Centers: 23.2" (590mm)

ETURNTABLE Material Support Turntable – Installed View



1327 Northbrook Parkway, Suite 400 Suwanee, GA 30024

www.tapetech.com

1-844-TT-TOOLS